



SECURILOCK / SLAMLOCK & DEADLOCK



HOW TO USE: SECURILOCK

The SecuriLock comes in two different variants: SlamLock and DeadLock.

SLAMLOCK / SL1-021-002

SlamLock means the door locks everytime you slam it shut. Best for vans holding high-value cargo such as pharmaceuticals, cannabis, tools and more.

DEADLOCK / SL2-021-002

DeadLock allows drivers to choose whether the lock stays active, or whether the lock is "dead". The difference is in the direction you turn the key - one disables the lock, one keeps it active.

Important Details:

- Locks come with 3 keys per vehicle
- To replace key, take a picture of supplied key card and send to installer or Legend. **DO NOT** throw card out.

SECURILOCK / DEADLOCK

TO LOCK:

1. Close door



2. Lift Dust Flap and Insert Key



3. Turn Left



4. Remove Key



TO UNLOCK:

1. Lift Dust Flap and Insert Key



2. Turn Right



3. Open Door



4. Remove Key



CONVERT DEADLOCK TO SLAMLOCK:

You can convert the DeadLock to a SlamLock by following four simple steps. Your vehicle door must be unlocked and

open in order to properly convert the mechanism. For help, contact info@legendfleet.com

1. While Open, Insert Key



2. Turn Key All The Way Left



3. Remove Key



4. Close Door



TO LOCK:

1. Close door



TO UNLOCK:

1. Lift Dust Flap and Insert Key



2. Turn Right



3. Open Door



EMERGENCY RELEASE:

In case of an emergency, there is a [red release button](#) located on the inside of the van. Simply pull the red button to yourself, unlock the SecuriLock, and exit the vehicle.



WARRANTY CARD

In the event of a lost key, or to replace the unit, take a picture of supplied warranty key card and send to installer or Legend. **DO NOT** throw card out.

